

# iFleetONE<sup>TM</sup>

## **Satellite Terminal**

User Manual  
Revision 3.1

**Technical Support:** [support@addvalue.com.sg](mailto:support@addvalue.com.sg)

Whilst the information in this User Manual has been prepared by Addvalue Innovation Pte Ltd ("Addvalue") in good faith, and all reasonable efforts have been made to ensure its accuracy, Addvalue makes no warranty or representation as to the accuracy, completeness, or fitness for purpose or use of the information. Addvalue shall not be liable for any loss or damage of any kind, including indirect or consequential loss, arising from use of the information and all warranties and conditions, whether express or implied by statute, common law or otherwise, are hereby excluded to the extent permitted by the law of Singapore. Addvalue, the Addvalue Enabled logo, Wideye, Wideye logo, IFleetONE, iFleetONE logo are either trademarks or registered trademarks of Addvalue Technologies Ltd and/or its affiliates in Singapore and/or other countries. Inmarsat, the Inmarsat logo registered trademarks of Inmarsat Global Limited in the United Kingdom and/or other countries, and are used by Addvalue Innovation Pte Ltd under license.

# List of Contents

<b>1</b>	<b>INTRODUCTION</b>	<b>8</b>
1.1	Fleet One Coverage	8
1.2	Services	10
1.3	Features	11
1.4	Interfaces	11
<b>2</b>	<b>MAIN UNITS</b>	<b>12</b>
2.1	Above Deck Equipment (ADU), Antenna Unit	12
2.2	Below Deck Equipment (BDU), Transceiver Unit	13
2.3	Optional Primary Handset	15
<b>3</b>	<b>GETTING STARTED</b>	<b>16</b>
3.1	System Configuration	16
3.2	Preparation for Operation	17
3.2.1	Installing the SIM Card	17
3.2.2	Connecting the Optional Primary Handset	17
3.2.3	Connecting Other Equipment	17
3.2.4	Powering Up the Terminal	18
<b>4</b>	<b>USING THE OPTIONAL PRIMARY HANDSET</b>	<b>20</b>
4.1	The Primary Handset	20
4.2	Powering Up the Primary Handset	21
4.2.1	Full functional mode	21
4.2.2	PIN mode	21
4.2.3	Emergency only mode	21
4.3	The Primary Handset (Optional Accessory)	22
4.3.1	Keypad - Description and Functions	23
4.3.2	The Main Display Screen	25
4.3.3	Primary Handset Operations	27
<b>5</b>	<b>USING THE WEB CONSOLE</b>	<b>49</b>
5.1	Register to the Network	49
5.2	Navigating the Web Console	52
5.2.1	Web Console Overview	52
5.2.2	Navigation Panel	53
	<b>GLOSSARY</b>	<b>100</b>



## CERTIFICATION



**FCC Identifier: QO4-WEFLONEVTWO**

## USE CONDITIONS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

### NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## IMPORTANT NOTE: EXPOSURE TO RADIO FREQUENCY RADIATION

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. The antenna used for this transmitter must be installed to provide a separation distance of **at least 1m** from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

## **FCC CAUTION:**

Any changes or modifications not expressly approved by the manufacturer could void the user's authority, which is granted by FCC, to operate this iFleetONE Maritime Satellite Terminal.

## **Industry Canada Statement:**

### **IC: 5023B-WEFLONEVTWO**

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

1. This device may not cause interference; and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage;
2. l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## CE RED DECLARATION OF CONFORMITY

Addvalue Innovation Pte Ltd  
Company Registration No: 199604379C  
8 Tai Seng Link, Level 5 (Wing 2), Singapore 534158  
Tel: +65 6509 5700 Fax: +65 6509 5701  
www.addvaluetechnology.com



## RED Declaration of Conformity

We,

Company : **Addvalue Innovation Pte Ltd**  
Address : 8 Tai Seng Link, Level 5 (WING 2), Singapore 534158  
Phone Number : +65 6509 5718  
Fax Number : +65 6509 5701

Declare under our sole responsibility that the product:

Product : Maritime Communication System, iFleetOne  
Brand Name : Wideye  
Type or Model : Fleet One V2  
Hardware version : 1  
Firmware version : R00.1.0.162  
Others : Antenna Unit: iFleetOne ADU - Maritime FleetBroadband Inmarsat Class 14 Radom Antenna  
Main unit: iFleetOne WIFI monopole antenna model: Monopole Antenna, 2dBi.  
Software and hardware of this product is not allowed to be changed or modified by end-user.

is in conformity with the following standards and/or technical specifications (References to standards/specifications must be listed with their identification number and version and, where applicable, date of issue)

Health & Safety (Article 3.1(a)) : EN 60950-1:2006/A2:2013  
EN 62311:2008  
EMC (Article 3.1(b)) : ETSI EN 301 489-1 V2.1.1: 2016  
Draft ETSI EN 301 489-19 V2.1.0: 2017  
ETSI EN 301 489-17 V3.1.1: 2017  
ETSI EN 301 489-20 V1.2.1: 2002  
EN 61000-3-2 :2014  
EN 61000-3-3 :2013  
EN 60945 :2002  
Radio Spectrum (Article 3.2) : EN 301 444 V2.1.2: 2017  
EN 300 328 V2.1.1: 2016  
EN 303 413 V1.1.1: 2017  
Other (Article 3.3) : NA

We hereby declare that the above-named product is in conformity to all the essential requirements of Directive 2014/53/EU with the involvement of the following Notified Body under Annex III Module B of the Directive for Article 3.2 only:

**Timco Engineering, Inc. 849 N.W. State Road 45 Newberry, Florida 32669 United States**

Identification Mark: **1177** Type Examination Certificate No: **TCF-1604SC17**

The technical documentation relevant to the above equipment will be held at:

Company (or name of EU representative) : Addvalue Innovation Pte Ltd  
Address (or address of EU representative): Singapore

Date: 29 August 2017

Name of Authorised Person: Garcia Day Villos  
Job Title: Manager, Reliability Engineering

Place of Issue: Singapore  
(e.g. City/town, and Country)

Note (not forming part of this declaration): The information required to identify all applicable Union acts should be available in a single EU declaration of conformity. In order to reduce the administrative burden on economic operators, that single EU declaration of conformity may be a dossier made up of relevant individual declarations of conformity. Please see Recital 42 and Article 18 of the RED.

Mobile Earth Stations (MES) 1668 – 1670 MHz is under restricted usage under ECC Decision ECC/DEC/(04)09 for EU Countries. User/Operator shall check with local Radio Spectrum regulator for necessary operating license and restriction usage and protection of Local Radio service.

AT	BE	BG	CZ	DK	EE	FR	DE	IS	IE	IT
EL	ES	CY	LV	LI	LT	LU	HU	MT	NL	NO
PL	PT	RO	SI	SK	TR	FI	SE	CH	UK	HR




## SAFETY INSTRUCTIONS



For safety and protection, read the manual before attempting to use the iFleetONE User Equipment (UE).

The following general safety precautions must be observed during all phases of operation, service and repair of this equipment. Failure to comply with these precautions or with specific warnings elsewhere in this user guide violates safety standards of intended use of the UE.

Addvalue Innovation Pte Ltd assumes no liability for the customer's failure to comply with these requirements.

### Hazard Symbols

<p><b>Hot Surfaces</b></p> 	<p>Avoid touching those areas of the UE that are marked with this symbol otherwise it may result in injury.</p>
<p><b>Antenna Radiation Warning and Distance to other Radiation Equipment</b></p> 	<p>For safety reasons, all personnel must keep at least <b>1 meter</b> from the antenna.</p>
<p><b>Power Supply</b></p> 	<p>Turn off the power at the mains switchboard before beginning of the installation.</p> <p>Confirm the power voltage is compatible with voltage rating of the equipment. It is highly recommended to use 12V - 24VDC, 12.5A - 6.25A power supply, provided that it is available on the vessel.</p> <p>If there is no suitable DC power line provided by the vessel, an external AC/DC power supply (input range of 100~240V AC, 50~60Hz) with an output of +24VDC, 6.25A can be used.</p> <p><b>Note:</b> The requirements of the AC/DC power supply should take care of <b>high surge current of 25A at 24V DC for 1ms.</b></p>

<p><b>Grounding, cables and connections</b></p> 	<p>The chassis of the equipment must be connected to an electrical ground. This will minimise electric shock and mutual interference. In short, the UE must be grounded to the vessel.</p>
<p><b>Service</b></p> 	<p>Do not attempt to access to the interior of the equipment. Only qualified personnel authorized by its manufacturer may perform service. Failure to comply with this rule will result in the warranty void.</p> <p>Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power before accessing the equipment.</p>

### Equipment Ventilation

To ensure adequate cooling of the terminal, 5 centimeters of unobstructed space must be maintained around all sides of the unit except the bottom side. The operational temperature range of the transceiver is: -25°C to +55°C.

### Fire Precautions

The equipment shall not be operated in the presence of flammable gases or fumes as well as any explosive atmosphere. Operation of any electrical equipment in such an environment constitutes a definite safety hazard.

### Obtaining Licensing For Inmarsat Transceivers

Under rights given under ITU Radio Regulations, local telecommunications administrations establish and enforce national rules and regulations governing types of emissions, power levels, and other parameters that affect the purity of signal, which may be radiated in the various frequency bands of the radio spectrum.

To legally operate Inmarsat equipment, it is necessary to obtain permission from the local telecommunications regulatory authorities of the country you are operating from. Using your equipment in any country without permission causes you to run the risk of confiscation of the equipment by the local authorities. The normal procedure to bring such equipment into another country is to apply for a license before travel. If a license has not been obtained before travel, the equipment may be put in to storage by local authorities until such time that a license is obtained.

## **IMPORTANT INFORMATION TO INSTALLERS AND USERS**

### **General**

It is important that the user of this equipment read and observe all safety requirements and operate the terminal according to the descriptions published in this manual.

Failure to comply may result in risk of injury or equipment failure and voids the validity of the warranty provided by equipment manufacturer.

The terminal consists of 2 units; the BDU and the ADU. They must be used as provided by the manufacturer or authorized dealer. Do not substitute any one part of the system which is not provided by the manufacturer or authorized dealer. Should servicing or replacement be required; always contact the distributor or manufacturer for instructions and assistance.

Any modifications or attempts to open the devices by non-authorized personnel will void the warranty.

Contents in this manual are subjected to change without notice and may contain errors or inaccuracies. The manual is periodically revised and updated. To obtain the latest version, please enquire about it from the product manufacturer or distributor.

### **RF Specifications**

#### **Operating Frequencies:**

Transmit : 1626.5 MHz - 1660.5 MHz and 1668 MHz – 1675 MHz

Receive : 1518 MHz – 1559 MHz

Transmit EIRP : 15.1 dBW

### **Copyright**

© Copyright 2021 Addvalue Innovation Pte Ltd.

All rights reserved. This publication and its contents are proprietary to Addvalue Innovation Pte Ltd. No part of this publication may be reproduced in any form or by any means without the written permission of Addvalue Innovation Pte Ltd.

## **Warranty**

Addvalue Innovation Pte Ltd. has made every effort to ensure the correctness and completeness of the material in this document. Addvalue Innovation Pte Ltd shall not be liable for errors contained herein. The information in this document is subject to change without notice. Addvalue Innovation Pte Ltd. makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

## **Trademarks**

All trademarks, marks, names, or product names referenced in this publication are the property of their respective owners, and Addvalue Innovation Pte Ltd neither endorses nor otherwise sponsors any such products or services referred to herein.

Microsoft, Windows, Windows NT, Windows 2000, Windows XP and Windows 7 are registered trademarks of Microsoft Corporation in the U.S.A. and/or other countries.

All other company and product names may be the registered trademarks or trademarks of their respective owners.

# 1 INTRODUCTION

The iFleetONE terminal is a dedicated compact solution designed to meet the Fleet One services requirements for the targeted maritime market segments. The Fleet One data service offers a throughput of up to 150 kbps. The service offers both voice and IP data connectivity which operates over Inmarsat's existing BGAN network.

**Note:** *The throughput is dependent on the local operating conditions and is likely to be less than 150 kbps in some locations.*


The terminal has been designed for maritime conditions, with ingress protection and compact dimensions for both above and below-decks equipment.

## 1.1 Fleet One Coverage

The Inmarsat Fleet One Service has two variants; the Fleet One Coastal service and the Fleet One Global service. The Fleet One Coastal service has a specific service plan and is only available in those green areas shown on the coverage map (see below).

## Coastal Fleet One Coverage


Fleet One Coastal coverage and rate regions



The **green** areas represent the voice and data services and they are known as the “**Home Region**” area. The area outside the home region is known as “**Out of Region**” which supports only voice service (including 505 emergency call). The network will disable data service if the vessel is outside the Home Region area.

The Fleet One Coastal service is available for vessels under 500 gross tonnages.

## Global Fleet One Coverage



The Fleet One Global service supports the data service throughout the entire Inmarsat coverage areas of Alphasat and I-4 constellation. There are no vessel size restrictions.

### 1.2 Services

- Email and webmail
- Secure communications
- Intranet and internet access
- SMS and instant messaging
- Phone service
- Large file transfers

### 1.3 Features

The iFleetONE offers the following features:

Services	Inmarsat Fleet One
Coverage	Voice and data are available globally except for the extreme polar regions.*
Voice	4kbps AMBE+2.
SMS	Standard 3G (up to 160 characters) per SMS. Maximum of 4 chained SMS.
Data	Standard IP: Up to 150 kbps

**Note:** Operates down to antenna elevation of 5° line of sight to the Inmarsat I-4 satellite (performance may be reduced further at lower elevation angles).

The UE supports both voice and data services simultaneously. The built-in Web Console allows you to manage your phone book, messages and calls, and to customize the terminal to your specific needs.

### 1.4 Interfaces

The iFleetONE UE has the following interfaces:

- +12V / 24V DC Power Input Connector
- Antenna Connector (N-Type)
- SIM Card Slot for Fleet One SIM card
- Dedicated Primary Handset Port
- GPS Output Port
- RJ11 Telephone Socket
- RJ45 LAN Socket
- GPIO

## 2 MAIN UNITS

The iFleetONE terminal includes the following main units:

- iFleetONE BDU
- iFleetONE ADU

The wired Primary Handset is an optional accessory.

### 2.1 Above Deck Equipment (ADU), Antenna Unit

The iFleetONE ADU is a mechanically stabilized maritime antenna. The antenna is self-tracking based on patented beam squint technology. Tracking is accomplished by measuring signals being continuously broadcast from the satellite.

- The radome covers the antenna unit, which comprises:
  - Antenna Module
  - RF and GPS Module
  - Rotary Joint
  - Antenna Pedestal

The antenna unit includes a low noise amplifier (LNA), high power amplifier (HPA), and tracking receiver circuitry to ensure communication even in adverse circumstances.



All signals (and DC power) pass through a single coaxial antenna cable, which connects the ADU to the BDU.

## 2.2 Below Deck Equipment (BDU), Transceiver Unit

The BDU has been developed for maximum flexibility and is the controlling unit for the iFleetONE UE. It features reliable industry standard interfaces and enables users to have optimal connectivity no matter what the conditions or your position at sea.



The BDU has a built-in Web Console, which can be accessed from a computer connected to the BDU, using a Web browser. The Web Console provides easy configuration of the BDU, firmware upgrade and daily use. For more information, see **Chapter 5, Using the Web Console**.

The BDU is supplied by a +12V or +24V DC power supply, and it supplies power to the ADU via a single RF/coaxial antenna cable.


### Status LEDs



There are 4 Status LEDs to indicate the operational status of the BDU. Each LED is assigned to the following function:

- BDU Terminal Status
- ADU Status
- Registered to Network Status
- Data Active Status


## SIM Card Slot



Lift and rotate the SIM Card slot protective cover to access the SIM card slot. The UE requires a dedicated Fleet One service SIM card to access the network and to configure the settings of the UE.

## Front Panel

The following diagram shows the front panel of the BDU.



- |                               |                         |
|-------------------------------|-------------------------|
| 1. Antenna (N-Type) Connector | 7. SIM Card Slot        |
| 2. Wi-Fi Antenna Connector    | 8. Primary Handset Port |
| 3. GPIO Port                  | 9. Grounding Stud       |
| 4. GPS Output Port            | 10. DC Power Connector  |
| 5. LAN Port (RJ45)            | 11. ON / OFF Switch     |
| 6. Phone Port (RJ11)          |                         |


## 2.3 Optional Primary Handset



The wired Primary Handset has a colour liquid crystal display (LCD) and keypad for making and receiving normal voice calls and sending SMSs using an interface similar to a mobile phone. The user may access various BDU functions via the handset. The Primary Handset connector is plugged into the BDU primary handset port and it is powered directly from the BDU.

### 3 GETTING STARTED

#### 3.1 System Configuration



**Solid line** refers to the basic configuration

## 3.2 Preparation for Operation

### 3.2.1 Installing the SIM Card

The terminal requires a Fleet One service SIM card to access the Inmarsat network and to configure the settings of the BDU. Your airtime service provider will be able to supply further information.

**Note:** *Ensure that the BDU is switched off before inserting or removing the SIM card.*

- Lift and rotate the SIM card slot protective cover and position the SIM Card (with its gold contacts facing down. Refer to the symbol of a SIM card labelled on the front panel to ensure the correct orientation of the SIM Card before it is inserted.)
- Push the SIM card gently into the slot until it is locked in place.
- Close the SIM card slot protective cover.



### 3.2.2 Connecting the Optional Primary Handset

- If supplied, plug in the Primary Handset connector into the Handset port on the BDU front panel and tighten the locking ring.



### 3.2.3 Connecting Other Equipment

- Connect a LAN cable (which is provided) between RJ45 port and a suitable laptop.
- Connect a telephone cable (which is not supplied) between RJ11 port and a PSTN handset (if required).



### 3.2.4 Powering Up the Terminal

- a. Use the ON/OFF switch on the BDU's front panel.



- b. Wait for the LED indicators (**TERMINAL**, **ANTENNA** and **REGISTERED**) to turn green to indicate the terminal is completely powered. Refer to the table below for meaning of the status indicators.



LED Name	Status	Meaning
TERMINAL	Steady <b>Amber</b>	Terminal (BDU) is powering up.
	Steady <b>Green</b>	Terminal (BDU) has powered up successfully.
	Steady <b>Red</b>	Terminal (BDU) has detected a failure state.
	Off	Terminal (BDU) is in OFF state.
ANTENNA	Steady <b>Amber</b>	ADU is powering up.
	Blinking <b>Amber</b>	ADU is calibrating.
	Blinking <b>Green</b>	System is performing satellite search.
	Steady <b>Green</b>	System has locked on to the satellite.
	Steady <b>Red</b>	ADU has detected a failure state.
	No light (Off)	ADU is in OFF state.
REGISTERED	Steady <b>Amber</b>	Attempting network registration
	Blinking <b>Amber</b>	Ready for Voice only.
	Blinking <b>Green</b>	Ready for Data only.
	Steady <b>Green</b>	Ready for all (Voice and Data).
	Steady <b>Red</b>	Network failure / Registration error.
	No light (Off)	No network service.
DATA ACTIVE	Steady <b>Amber</b>	Activating data connection.
	Steady <b>Green</b>	Data connection is ready.
	Steady <b>Red</b>	Data activation failure
	No light (Off)	No data connection.

## 4 USING THE OPTIONAL PRIMARY HANDSET

### 4.1 The Primary Handset

The Primary Handset is an optional accessory and is connected to the iFleetONE UE using the dedicated HANDSET port and is powered directly from the BDU. Equipped with a large 2", 65K color, TFT, 220 x 176 pixel Liquid Crystal Display (LCD), the Primary Handset not only acts as a standard phone that allows you to make and receive voice calls, it also serves as a remote access device to access various configurations supported by the BDU.

Primary Handset offers the following features:

- Making standard CS voice calls
- Making standard PS background data connections
- Messaging (SMS)
- User contacts (combined SIM and BDU storage)
- Speed dial
- Call logs
- Managing BDU security settings
- Accessing BDU settings that includes:
  - Ethernet options
  - Ciphering control
  - Supplementary services
  - Transceiver restart
  - Limited factory reset
- Displaying various BDU status and information
- Local handset configurations



## 4.2 Powering Up the Primary Handset

The Primary Handset is automatically powered up once it is connected to the dedicated **HANDSET** port. Depending on the conditions of the BDU, the Primary Handset may start in the following modes:


### 4.2.1 Full functional mode

In full functional mode, there is no PIN authentication required to start using the iFleetONE terminal. All BDU settings including contacts, messages and call logs are loaded into the local memory of the Primary Handset once the BDU is configured. You will be able to access all the menus and make voice or data calls once the Primary Handset is ready.



### 4.2.2 PIN mode

User is required to enter the correct PIN/password before proceeding to **Full functional mode**, refer to the **Security settings** menu for more information on the types of security PIN for the BDU.

#### To enter the PIN:

1. Key in the security key PIN using the alpha-numeric keypad.
2. Press  key to confirm.


#### To cancel PIN entering:

1. Press the Right  selection key.
2. Confirm to start in Emergency only mode by pressing the  key.

### 4.2.3 Emergency only mode

PIN authentication is bypassed (i.e. if you have forgotten the required PIN). You can only make emergency calls or access the Phone manager menu in this mode.







### 4.3 The Primary Handset (Optional Accessory)






1. Earpiece
2. Display
3. Ear-set Jack
4. OK Key
5. 4-Way Navigation Keys
6. Select Left Key
7. Select Right Key
8. Call/Send key
9. End key
10. Keypad (Alpha-numeric)
11. Mode Key
12. Clear Key
13. Microphone
14. Service Port
15. Ringer\*


**Note** :\* The ringer is located at the back of the Primary Handset.

### 4.3.1 Keypad - Description and Functions

Keys	Description/Functions
	<b>4-way navigation ring</b>  Press the 4-way navigation ring to scroll left, right, up, and down on the display. Enables scrolling through names, phone numbers, menus or settings.
	<b>OK key</b>  Pressing this key selects/confirms the function highlighted on the display.
	<b>Left selection key</b>  The function of this key depends on the guiding text shown on the display above the key.
	<b>Right selection key</b>  The function of this key depends on the guiding text shown on the display above the key.
	<b>Call/Answer key</b>  <b>After entering a phone number:</b> Initiates a call to the number.  <b>From Main Display screen:</b> Opens a list of dialed calls  <b>When Ringing:</b> Answers the incoming call.
	<b>Call/Menu End key</b>  Press this key to end active calls or exits from any menus or sub menus.

	<p><b>Keypad</b></p> <p>Used to enter numbers and characters. Press 0 to add a space when writing text.</p> <p>The functions available depend on whether you are typing a phone number (number mode) or text (text mode).</p>
	<p><b>Star * key</b></p> <p>When entering a phone number, press this key to insert a *. Press and hold this key to insert a +.</p> <p>When writing text, press this key to access a list of special symbols.</p>
	<p><b>Hash # key</b></p> <p>When entering a phone number, press this key to insert a #.</p> <p>To quickly change the text input method when writing text, press this key repeatedly and check the indicator at the top of the display.</p> <p>In standby mode, press and hold this key to set the Primary Handset into silent mode.</p>
<p><b>MODE</b></p>	<p><b>Mode key</b></p> <p>Unplug the handset from BDU. Press and hold this key when the handset is unplugged and then reinsert the plug to the BDU. The handset powers up in Firmware Upgrade Mode.</p>
<p><b>C</b></p>	<p><b>Clear Key</b></p> <p>Press key once to clear one character at a time or press and hold this key to clear the whole text entry.</p>

### 4.3.2 The Main Display Screen



- **BDU Status Indicator line**

The indicator line shows status symbol informing you about the operating conditions of the BDU.

- **Satellite**

The indicator line shows status symbol informing you about the satellite service.

- **Handset Status Indicator line**
















The indicator line shows status symbols informing you about the operating conditions of the Primary Handset.

- **Selection Key line**

The Selection key line operates using the Left  or Right  selection keys with the  key to access menus and controls.

## Primary Handset Status Indicators



Table below explains the meaning of each status indicator displayed in the Main Display screen.

Status Indicator	Description
	New short message (SMS) in inbox.
	Available CS domain services.
	Available PS domain services.
	Data connection is active.
	Ciphering is enabled.
	Radio silent is enabled.
	Primary Handset keypad lock is active.
	Primary Handset disconnected from BDU.
	Primary Handset connected to BDU.
	The terminal has locked on to Inmarsat satellite "I-4 Asia Pacific".
	The terminal has locked on to Inmarsat satellite "I-4 EMEA".
	The terminal has locked on to Inmarsat satellite "I-4 Americas".
	The terminal has locked on to Inmarsat satellite "I-4 MEAS".
	Primary Handset in silent mode.
	Signal strength.

### 4.3.3 Primary Handset Operations


#### Making a Voice Call

Before making a voice call, please make sure that:


- The Primary Handset is connected to the BDU. (  Status indicator should be on.)
- The Primary Handset is NOT radio silent. (  Status indicator should be off.)
- The BDU has successfully registered with the network and is ready for CS domain (voice) services. ( Status indicator should be on.)

You can use the following two options for making a call:


- **Manual Dial:**

1. Using the alphanumeric keypad, dial 00 <country code> <phone number>.
2. Press  key.

- **Using Contacts or Call Log list from the Primary Handset:**

Enter the **Contacts** list of the Primary Handset; scroll to the desired number and press  key, or

Enter the **Log** list of the Primary Handset; scroll to the desired number and press  key.

**Note:** For voice calls and SMS, you may also use '+' by pressing and holding the  key instead of "00" at the beginning of dialled number string as an alternative ('+' <country code> <phone number>).


#### To End a Call

Press  .

## Receiving a call


When there is an incoming call, the Primary Handset will ring.

The calling party's number will be displayed on the screen. If the number is stored in the contact, the corresponding name of contact will be displayed.


To answer an incoming call, press the  key.

## Adjusting volume during a call

Use the 4-way navigation ring  to adjust the volume.



## Using the Menus

You can access the Menu System by pressing the Right  selection key in the Main Display screen.

The main menu of the Primary Handset includes nine (9) menu options with each menu option having their respective sub-menus.














You can use the 4-way navigation  ing to navigate to the desired menu option and press  to confirm your selection. You can also end the menu or sub menus and return to the Main Display screen at any time by pressing the  key.


Table below summarizes the functionalities within each menu option:


	<b>Contacts</b> This menu manages your user contacts.
	<b>Log</b> This menu allows you to view call histories.
	<b>Telephony</b> This menu configures settings related to CS voice telephony services.
	<b>Data</b> This menu configures settings or connections related to PS data services.
	<b>Messaging</b> This menu is for SMS related services.
	<b>Settings</b> This menu configures general BDU settings.
	<b>Transceiver</b> This menu displays general BDU information.
	<b>Security settings</b> This menu configures security settings related to the <b>BDU</b> .
	<b>Phone manager</b> This menu configures local handset settings.




## Contacts Menu



The **Contacts** menu allows you to store, retrieve and update names and phone numbers of your contacts in the SIM card memory. You can also access this menu by pressing Left  selection key in Main Display screen.


This menu lists all the contacts saved in the SIM card memory where,  indicates contacts that are saved in SIM card.

The following options are available when pressing the Left  selection key while browsing through the contacts:

- **New contact**

Add new contact to the memory. To add contact:


1. Select **New contact**.
2. Select where you want to store the contact (BDU or SIM).
3. Enter the name for the contact.

**Note:** Press  key to browse for symbols.



4. Enter the number for the contact.

**Note:** Stored number can be in any one of the following formats:

- '+' <country code> <phone number>
- 00 <country code> <phone number>

Press  key to insert '+' sign.

Saving a contact without a telephone number is not allowed.

5. Select Save (Left  selection key) or pressing the  key to save the contact to the selected memory.

**Note:** Refer to "Tips for writing the text" section under New message for more information on text writing.

- **Search**

Select this to enter a specific name to search within the contact list.

- **Delete**

Delete selected contact.

Note: You can also delete the selected contact by pressing the Clear key.

- **Copy**

Select this to copy the selected contact from SIM card memory to BDU memory or vice versa.

- **View number**

Display the number of the selected contact.

- **Assign Speed Dial**



Add the selected contact to the speed dial list.

- **Reload Contacts**

Select this to reload contacts from the BDU/SIM card into the local memory of the Primary Handset.

- **Memory Status**

Select this to view the memory status available for contacts.

While browsing through the contact list, press the  key to view the phone name and number or the selected contact. The following options are available when pressing the Left  selection key while viewing the selected contact:

- **Call**

Make a voice call to this contact.

- **Send message**

Open a SMS editor to send a text message to this contact.

- **Edit contact**

Edit information of this contact.

- **Delete**

Delete this contact.

- **Copy**


Select this to copy this contact from SIM card memory to BDU memory or vice versa.

- **Forward contact**

Forward information of this contact using SMS.


- **Assign Speed Dial**

Add this contact to the speed dial list.

**Note:** You can also make a voice call to the selected contact when browsing through or viewing the contacts by pressing the Call  key.



**Log Menu**



The **Log** menu allows you to view historical information about phone calls and data usage in chronological order with the following sub menus:



**Missed calls**




**Received calls**



**Dialed calls**

Call history of the particular category is displayed in chronological order when selected. Up to 5 latest entries of each category can be saved.

The following options are available when pressing the Left  selection key while browsing through or viewing the call log:

- **Delete**

Delete the selected log entry from the list.

**Note:** You can also delete the entry by pressing the Clear **C** key.

- **Call**

Call the number in the selected log entry.


- **Send**

Send an SMS to the number in the selected log entry.

- **Save**

Save the number from the selected log entry to the contact list.

**Note:** This option is not available when the log entry already has an entry in the contact list.

You can also make a voice call to the number of the selected log entry when browsing through or viewing the call log by pressing the Call  key.



### **Clear call lists**


Select this to clear the call log entries. Available log options are:

- Missed calls
- Received calls
- Dialed calls
- All calls

Delete all logs including Missed, Received and Dialed logs.




### **Call/Data usage**

Display the accumulated call duration and data bytes. Press Left  selection key to clear the call or data duration volume.



### **Telephony Menu**



The **Telephony** menu allows you to configure telephony related settings with the following sub menus:




### **Speed dial**

- **Setting**




Contain options to enable/disable the speed dial feature.

- **Speed Dial List**

Select this to configure the speed dial list. The following options are available when pressing the Left  selection key while browsing through the list:

- **Assign**

Assign a contact to the selected entry. To assign a contact:

1. Select **Speed Dial List**.
2. Browse through the list to locate an empty entry.
3. Select **Options** by pressing Left  selection key.
4. Select **Assign** and press  from the option.
5. Select the desired contact to assign to the speed dial list.
6. Press  to confirm your selection.


- **Delete**


Remove contact from the selected entry. This option is not available for an empty entry.

**Note:** You can also delete the entry by pressing the Clear  key.

- **Call**


Make a call using the number from the selected entry. This option is not available for an empty entry.

**Note:** You can also make a voice call to the number of the selected entry by pressing the Call  key.

You can make a voice call directly from the Main Display screen by pressing the corresponding speed dial entry number + Call  key once the speed dial feature is enabled with a valid contact entry.



## Data Menu



The **Data** menu provides the following sub menus to manage and configure data connections (PDP profiles) for the BDU:




## Manage profiles

Allows you to manage the Primary PDP profile.

- Standard profile

One **Standard** Primary PDP profile has been created in the Primary profile list as a default profile.

You can press the Left  selection key for options available when browsing through the profile list. The list of options is:

### Edit

Edit the profile.

### Delete

Delete the profile.

- **Editing profiles**

You can press the Left  selection or  key from the option list to add new or edit existing profile settings.

### Profile name

Specify the name of the profile.

### Connection type

**Standard** connection type is supported.

- **APN**

Specify information for the APN (Access Point Name). Further available settings are:

**APN:** Specify the Access Point Name for the connection. Default APN is taken from the SIM card. Enter your own APN if you do not want to use the default APN.

**Username:** Specify the user name for Static IP configuration. Default is blank for Dynamic IP configuration.

**Password:** Specify the password for Static IP configuration. Default is blank for **Dynamic** IP configuration.

You can press the Left  selection key for the following options:

- **Edit**

Edit the selected APN setting.

- **Fetch from SIM**

Fetch the APN from the SIM card. This option is only available when APN is highlighted.

- **IP configuration**



Contain options for **Static** or **Dynamic** IP. Default is Dynamic.



- **IP address**

Specify the IP address for **Static** IP configuration. This field is ignored for Dynamic IP configuration. Default is blank for **Dynamic** IP configuration.

- **Header comp**

Contains options to enable or disable header compression. Default is **Enabled**.

**Note:** You will be prompted to save the changed settings before exiting the sub menu. Press Left  selection key or  key to save the changes.


Icon  in the profile list indicates that the profile is not active and icon  indicates that the profile is currently active in use.



## Status

Allows you to check the status of the data connection. You can also activate/de-active a specific profile in the status display list.

**Note:** You will not be able to enter this sub menu if the BDU has not been registered for PS data service.

The status list shows you the current active data connection. Depending on whether there is an active connection, you can press the Left  selection key for the following options:








- **Activate primary**

This option is available when there is no active data connection. Select this to choose from the profile list for activation.

- **Deactivate**






This option allows you to deactivate an active data connection.

### To active a primary data connection when there is no active connection:

1. From the data status list, select Options using the Left  selection key.
2. Select **Activate primary** using Left  selection key or  key.
3. Select from a list of configured primary profile for activation. Press Left  selection key or  key to confirm.
4. You are prompted to confirm activation. Confirm activation by selecting Yes using the Left selection  key or  key.


**Note:** It may take a short time to active a data connection.

### To de-activate a primary data connection when there is an active connection:

1. From the data status list, select Options using the Left  selection key.
2. Select **Deactivate** using Left  selection key or  key.
3. You are prompted to confirm de-activation. Confirm de-activation by selecting Yes using the Left  selection key or  key.



## Messaging Menu







The **Messaging** menu allows the user to write new messages, view stored messages from **Inbox**, **Drafts** and/or **Sent** folders and configure settings related to SMS with the following sub menus:




## New Message

Select this to create and send a new message. To create new message:

1. Select **New Message** by pressing the  key. A SMS editor will be displayed on the Primary Handset screen for writing new message.
2. Type in your SMS message using the alphanumeric keypad.
3. To send the message, press the  key and select Send.
4. Enter the recipient's phone number, and press the  key. Alternatively you can select **Search** by pressing the Left  selection key to select the phone number from the contacts.

Options:

You can press the Left  selection key to select options available when writing the message.

- **Send**

Select this when you are ready to send your message.


- **Save**

Select this to save the message into the **draft** folder.

- **Clear screen**

Select this to clear all the written text.




**Tips for writing the text:**

- Press the 0 key to add a space.
- To quickly change the text input mode when writing text, press  key repeatedly and check the indicator at the top of the display:



**<ABC>:** Capital letters  
**<123>:** Numbers  
**<abc>:** Small letters  
**<Abc>:** Initial Capital letter followed by small letters

- To add a number in alphabet mode, press and hold the desired number key.


**Inserting symbols to your message:**

- To get a list of special symbols, press the  key.
- Using the 4-way navigation ring , navigate to the desired symbol.
- Press  to confirm selection.

**Clearing text:**

- To clear text, press  once to clear one character at a time.
- To clear the whole text entry, press and hold  to clear the whole text entry.

**Inbox**


Contains new/opened text messages that you have received. When browsing through the messages list using the 4-way navigation  ring,




Indicates an unread (new) message and



Indicates read (opened) text messages.

The following are available options when pressing the Left  selection key while browsing through or viewing the messages in this folder:

- **Open**

Open selected message. You can also press  while browsing through the message list to open the selected message (This option is not available when viewing the message).

- **Reply**

Select this to reply to the selected message sender.

- **Delete**

Delete selected message.

**Note:** You can also delete the selected message by pressing the Clear **C** key.

- **Forward**

Forward this message to another recipient.

- **Call**

Make a voice call to the selected message sender.

- **Save**


Save the selected message into the Draft folder.

- **Details**

Display the details of the selected message


- **Add to contact**

Select this to add the phone number of the selected message into the contact list.


**Note:** You can also make a voice call to the selected message contact when browsing through the messages list by pressing the Call  key.



## Sent

Contain text messages that you have sent. The following are available options when pressing the Left  selection key while browsing through or viewing the messages in this folder:

- **Open**

Open selected message. You can also press  while browsing through the message list to open the selected message (This option is not available when viewing the message).

- **Delete**

Delete selected message.

**Note:** You can also delete the selected message by pressing the Clear **C** key.

- **Send**


Send the selected message to another recipient.

- **Save**

Save the selected message into the Draft folder.


- **Add to contact**

Select this to add the phone number of the selected message into the contact list.


**Note:** You can also make a voice call to the selected message contact when browsing through the message list by pressing the Call  key.



#### Draft

Contain text messages that you have saved. The following are available options when pressing the Left  selection key while browsing through or viewing the messages in this folder:

- **Open**

Open selected message. You can also press  while browsing through the message list to open the selected message (This option is not available when viewing the message).

- **Delete**

Delete selected message.

**Note:** You can also delete the selected message by pressing the Clear **C** key.

- **Send**


Send this message to another recipient.

- **Save**

Save the selected message into the Draft folder

- **Add to contact**

Select this to add the phone number of the selected message into the contact list.

**Note:** You can also make a voice call to the selected message contact when browsing through the message list by pressing the Call  key.



#### Options

The following settings are available in this sub menu:

- **Message Centre**

Select this to set the number of the SMS service centre.

- **Save sent message**

Select this to enable or disable the saving of sent messages. When this option is enabled, all successfully sent messages are saved in the Sent folder.

- **Memory status**

Select this to view the memory status of the messages.

- **Reload Messages**

Select this to reload messages from the BDU into the local memory of the Primary Handset.



- **Delete all**

Select this to clear the messages in a particular folder. Available folder options are:

- **All messages**

Delete messages in all folders including Inbox, Sent and Draft.


- **Inbox**

- **Sent**

- **Draft**



- **Settings Menu**



The **Settings** menu provides the following sub menus to configure the BDU:




- **Ciphering mode**

Contain options to enable/disable the use of ciphering mode between the network and BDU.

**Note:** Status icon  is displayed in the Main Display screen when ciphering is enabled.



## Terminal Menu



The **Terminal** menu provides the following sub menus to check for information and perform resets on the BDU:



### Signal strength

Shows graphical representation of current signal strength and GPS type. Table below describes the available GPS type icons used in this sub menu:

	This icon shows that the BDU is in the process of acquiring a GPS fix when there is no previously stored GPS fix.
	This icon shows that the BDU is using New GPS coordinates.
	This icon shows that the BDU is using previously stored GPS coordinates.



### GPS status

Show current Latitude and Longitude coordinates the GPS type and Time of acquisition by the BDU.



### Terminal Info

Display a list of information about the BDU.

- **Manufacturer**

Manufacturer's name of the BDU

- **Software version**

Software version of the BDU

- **Model**

Model name of the BDU

- **IMEI Number**

IMEI number of the BDU

- **IMSI Number**

IMSI number of the SIM card

- **Subscriber Number**

Subscriber's telephone number

- **Serial Number**

Serial number of the BDU.



### **ADU Info**

Display a list of information about the Antenna.

- **Serial Number**

Serial number of the Antenna.

- **ATB SW version**

Software number of the Antenna ATB.

- **ATB HW version**

Hardware number of the Antenna ATB

- **HPA SW version**

Software number of the Antenna HPA.

- **HPA HW version**

Hardware number of the Antenna HPA.



### **Terminal restart**

Soft restart of the BDU.



### **Limited reset**


Performs a limited reset of the BDU. Apart from a full factory reset that is not available from the Primary Handset, a limited reset only resets a small portion of the BDU settings. Stored GPS status, contacts, call logs and event logs are not cleared during limited reset.

You are also required to key in the password when performing the reset. The default password is 0000.

**Note:** This password is the same as Terminal PIN.



## Security settings Menu



The **Security Settings** menu provides the following sub menus to configure the security settings of the BDU using a different PIN:



### Terminal PIN



### SIM PIN

There are three options available for selection under each sub menus to manage the PIN and security settings for the BDU:

#### Enable

Enable the selected PIN. The table below summarizes the default PIN codes for each security setting:

Terminal PIN	0000  <b>Note:</b> Terminal PIN is the same PIN that has to be entered when performing a Limited Reset on the BDU.
SIM PIN	Depends on your SIM card. Consult your equipment distributor if necessary.  <b>Note:</b> You have to enter the PUK (PIN Unblocking Key) to access the SIM card if a wrong PIN for SIM PIN has been entered three times. You will be asked to enter the new PIN code once you have entered the correct PUK. However, the SIM card is no longer usable if you have entered an incorrect PUK for 10 attempts.

You will be asked to key in the existing PIN (or default PIN if it has not been changed) before the PIN can be enabled.

- **Disable**

Disable the selected PIN. You will be asked to key in the existing PIN (or default PIN if it has not been changed) before the PIN can be disabled.


- **Change**

Change the PIN to a new one. You will be asked to key in the existing PIN (or default PIN if it has not been changed) before the PIN can be changed.

**Note:** PIN has to be enabled before it can be changed.



### Phone manager Menu



The **Phone manager** menu provides the following sub menus to configure settings that are local to the Primary Handset:



### Display

Configures settings that are related to Primary Handset display.

- **Backlight**

To set the duration of the display backlight to remain on. Settings range from Always On (Backlight permanently turned on), or 15 seconds to 1 minute.

**Note:** The backlight will be slightly dimmer and finally turn off when there is no keypad activity after sometime. However, this feature is not available when the setting is set to Always On.



## Tone

Configures tone setting for the standard and ring tones.

- **Standard tone**

- **Key tone**


Contains options to enable/disable the key tone.

- **Message tone**

Contains options to enable/disable the message tone.

- **Volume**

Configures the volume for the standard tones (both key and message tones). Using the


4-way navigation ring , press up/right to increase and down/left to decrease the volume.

- **Ring tone**

- **Tone**

Selects desired ring tone pattern.

- **Volume**

Configures the volume of the ring tone. Using the 4-way navigation ring , press up/right to increase and down/left to decrease the volume.



## Language

Allows you to change the menu display language.



## Factory reset

Allows you to configure default factory settings of the Primary Handset. Contains the following settings:

- **Factory reset**

Perform factory reset on the Primary Handset



## About

Displays a list of information of the Primary Handset.

- **Model**

Model name of the Primary Handset

- **Software version**

Software version of the Primary Handset

- **Hardware version**

Hardware version of the Primary Handset

- **Copyright**

Contains Copyright message

## 5 USING THE WEB CONSOLE


### 5.1 Register to the Network

- a. Connect your computer to the iFleetONE BDU using a LAN cable.
- b. When the connection has been established, open the web browser (for example: Internet Explorer, Google Chrome or Firefox.).



- c. Type **http://192.168.1.35** in the Address field.
- d. Username and Password will be prompted.

Default Username : admin  
Password : 1234

A screenshot of a login interface on a black background. It features two white input fields. The first field is labeled 'Username:' and contains the text 'admin'. The second field is labeled 'Password:' and is empty. Below the fields is a blue button with the text 'Login' in white.

- e. Click “**Login**” button after entering the Username and Password.

- f. When using the terminal for the first time, you will be prompted to change the password.

≡Home

Change Password

Change Password

Username:	admin
Old Password:	....
New Password:	.....
Re-enter New Password:	.....

Update

**Note:**  
For maximum security, password should be min 6 characters long and a combination of uppercase and lowercase letters, numbers and symbols.

Password Strength: **Medium**

- g. After entering the new password and click **Update**, enter the new password and then click **Login**.

Username:

admin

Password:

Login

The BDU Web Console will appear on the screen.

Home

Home

Status:

Registered to network	Yes
Data connection active	No

Activate Data Connection

Signal:

65 dB

GPS:

Last acquired:	Fri Mar 25 2016, 22:50:36 UTC+0800
Lat:	40° 31' 58.72" N
Long:	3° 39' 21.41" W
Type:	3D (NEW)

Temperature:

Normal

Registered to Network but no active data connection exists. You are now able to make phone calls and send SMSs. Please activate a data connection before doing any data transfer.

Data

Phone

SMS

Settings

Logout



**WARNING:** If the signal strength is low (< 50 dB), check any obstruction against the antenna unit or the condition of antenna cable.

The terminal will proceed automatically to “**Checking PIN** status” followed by “**Antenna Pointing**” and then registering to the network (upon power on). This process takes 1.5 to 2 minutes to complete.

Once the process is completed, you will see the following message appearing at the bottom line of the Web Console.

**“Registered to Network but no active data connection exists. You are now able to make phone calls and send SMSs. Please activate a data connection before doing any data transfer.”**


Upon successful registration, with 3 BDU's LED indicators (“**TERMINAL**”, “**ANTENNA**” and “**REGISTERED**”) lit in green, the UE will be ready for normal operation.

## 5.2 Navigating the Web Console

### 5.2.1 Web Console Overview

In the Web Console, there is a selection of “**Home**”, “**Menu**” and “**Logout**”.

- a. Click “Home”, the screen will display;



On the Home page, it displays the status, signal strength, GPS information and temperature status of the UE.

Status	Indicates the status of network registration and data connection active (based on its activation or deactivation button).
Signal	Indicates the received signal strength (C/No in dB)
GPS	Indicates the last acquisition of date and time, latitude, longitude and type of GPS.
Temperature	Indicate the UE's current status of temperature status.

On the Navigation Panel, you can click a menu item of **Data**, **Phone**, **SMS**, **Settings** and **Logout**. More information of each menu item is described in the section of Navigation Panel.

- b. Click “Menu”, the screen will display with the menu items;




- c. Click “Logout” which is self-explainable.


## 5.2.2 Navigation Panel

### a. Data Menu

Click on **Data** Menu




The Data Menu provides the following options;



### 1. Data Profile

Data profile defines the connection type. You can create your own customized profile. Click **Data Profile**



Click **Add** to create a new data profile.

Home

Data

Data Profile

Data Profile

Profile Name:

Profile Name:

☒ Set as default

Data Connection #1

Access Point Name (APN):

☒ SIM

BGAN.INMARSAT.COM

☐ User Defined

Static IP Address APN Username:

admin

Static IP Address APN Password:

.....

Please note that the 'username' and 'password' stated above are not those used to login to the WebConsole. They are those provided by your Service Provider for a static IP address subscription. If you do not have any such a subscription or if you are not sure, please leave them blank.

Update Settings

Delete

Cancel

## Profile Name

Change the profile name as desired.

## Access Point Name (APN)

By default, the APN from the SIM will be selected.

Follow these steps to change the Access Point Name (APN):

- i. Select **User Defined**.
- ii. Enter the new APN in the field space provided (e.g. BGAN.inmarsat.com).
- iii. Enter the **Static IP Address APN** username and **Password** (provided by your Service Provider) if required. Otherwise please leave them blank if you do not subscribe the static IP address option.
- iv. Click **Update Settings** to save the data profile.

## 2. Data Settings

Navigation: Home | Data | Data Settings

**Data Settings**

☐ Always On (Auto PDP Context Activation)

Update Refresh

To enable Auto PDP Context Activation, click “**Always On (Auto PDP Context Activation)**” button and apply Update.

**Note :** After enabling the “Always On (Auto PDP Context Activation)”, it will take effect only upon the next reboot or power cycle terminal.

## 3. Firewall

Navigation: Home | Data | Firewall

**Setup**

**HTTP Filters**

### Setup

Click **Setup**.

By default, the **Firewall** is disabled.

Navigation: Home | Data | Firewall | Setup

**Setup**

**Firewall:** ☐ Enabled ☒ Disabled

Update Edit Refresh

To enable Firewall, select **Enable** and click **Update**.

Home
Data
Firewall
Setup

Setup

Firewall:

☒ Enabled
☐ Disabled

Profiles:

Profile1 ▼

Update

Edit

Refresh

With a selected profile (the maximum of 4 profiles allowed), click **Edit** to include an incoming rule or outgoing rule. Click both **Incoming Rule** and **Outgoing Rule** to expand

Home
Data
Firewall
Setup

Setup

Name:

Profile1

Update

Refresh

Close

Incoming Rule

Unless rules are specified, default behavior for all packets ☐ Accept ☒ Reject

Rule Name	Enabled
<< < 1 2 3 4 > >>	

Add

Update

Refresh

Close

Outgoing Rule

Unless rules are specified, default behavior for all packets ☐ Accept ☒ Reject

Rule Name	Enabled
<< < 1 2 3 4 > >>	

Add

Update

Refresh

Close

© 2021 Addvalue Innovation Pte Ltd. All rights reserved.

57

For an **Incoming Rule**, click **Add** to allow or reject incoming packets with options of type of protocol, source IP address and port, and destination IP address and port.

Incoming Rule	
Rule Name:	<input type="text" value="Rule1"/>
Protocol:	<input checked="" type="radio"/> TCP <input type="radio"/> UDP <input type="radio"/> ICMP <input type="radio"/> ANY
Source IP Address:	<input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> / <input type="text"/>
Source Port:	<input type="text"/> - <input type="text"/>
Destination IP Address:	<input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> / <input type="text"/>
Destination Port:	<input type="text"/> - <input type="text"/>
Action:	<input checked="" type="radio"/> Allow <input type="radio"/> Reject
<div> <input type="button" value="Apply"/> <input type="button" value="Clear"/> <input type="button" value="Cancel"/> </div>	
<small>Note: IP Addresses, Ports with value 0 means ANY. eg. IP (0.0.0.0 / 0) means ANY IP, Port (0 - 0) means ANY Port.</small>	

Click **Apply** to take effect.

For an **Outgoing Rule**, click **Add** to allow or reject outgoing packets with options of type of protocol, Source IP address and port, and Destination IP address and port.

Outgoing Rule	
Rule Name:	<input type="text" value="Rule1"/>
Protocol:	<input checked="" type="radio"/> TCP <input type="radio"/> UDP <input type="radio"/> ICMP <input type="radio"/> ANY
Source IP Address:	<input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> / <input type="text"/>
Source Port:	<input type="text"/> - <input type="text"/>
Destination IP Address:	<input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/> / <input type="text"/>
Destination Port:	<input type="text"/> - <input type="text"/>
Action:	<input checked="" type="radio"/> Allow <input type="radio"/> Reject
<div> <input type="button" value="Apply"/> <input type="button" value="Clear"/> <input type="button" value="Cancel"/> </div>	
<small>Note: IP Addresses, Ports with value 0 means ANY. eg. IP (0.0.0.0 / 0) means ANY IP, Port (0 - 0) means ANY Port.</small>	

Click **Apply** to take effect.

## HTTP Filters

Select option **Enabled** and then click **Update**.

☰ Home   Data   Firewall   HTTP Filters

### HTTP Filters

**Hostname Filters:** ☒ Enabled ☐ Disabled

Update

*Note: Hostname filters will only take effect when HTTP/HTTPS rules are enabled (allowed)*

Hostname/Keywords
Text

<< < 1 > >>

Add Edit Delete Refresh

To block any keyword in the content of the accessed page, click **Add** with the keywords in the field and then **Apply** to take effect.

☰ Home   Data   Firewall   HTTP Filters

### HTTP Filters

**Hostname Filters:** ☒ Enabled ☐ Disabled

Update

*Note: Hostname filters will only take effect when HTTP/HTTPS rules are enabled (allowed)*

Hostname/Keywords
Text

<< < 1 > >>


Add Edit Delete Refresh

**Hostname or hostname keywords:**

Apply Cancel

## b. Phone Menu

Click on **Phone** menu



The **Phone** menu has the following options;



### 1. Phonebook

- The Phonebook entries can be stored on either the SIM card or the Terminal
- It allows you to view, add, edit and delete entries in the Phonebook list.
- You can make and send SMS messages directly from your Phonebook entries.

### View option

The View option allows you to view the Phonebook entries from the different storage locations.

From the drop-down menu, select:

SIM Only	To view the entries stored in the SIM card.
Terminal Only	To view the entries stored in the iFleetONE BDU.
All	To view the entries stored in the SIM card and iFleetONE BDU.

### Storage Usage

Shows the number for Phonebook entries used in the SIM card and Terminal locations.

For example: (**SIM - 2/250**) indicates:

Storage location : **SIM card**  
 Total number of entries used : **2**  
 Total number of entries available : **250**

Likewise for (**Terminal - 0/100**)

### Adding a new Phonebook entry

- i. Click **Add**.
- ii. Enter the Name and Phone number.
- iii. Select the storage location and click **Add**.

Home

Phone

Phonebook

Phonebook

Name	<input type="text"/>
Phone no.	<input type="text"/>
Save Phonebook record in	<input checked="" type="radio"/> SIM <input type="radio"/> Terminal
<div>Add</div> <div>Cancel</div>	

### Editing a Phonebook entry


- Select the entry from the Phonebook list.
- Click **Edit** to change **Name** and/or **Phone no.**

Home

Phone

Phonebook

Phonebook

View option	<input type="text" value="All"/>	
Storage Usage	(SIM - 1/250) (Terminal - 0/100)	
Name	Phone no.	
 Technical	+6598201820	

<<

<

1

2

3

4

5

>

>>

Add

Edit

Delete

Send SMS

Refresh

1 row(s) are selected.

Click **Edit** to take effect.

Home

Phone

Phonebook

Phonebook

Name	<input type="text" value="Technical"/>
Phone no.	<input type="text" value="+6598201820"/>
<div>Edit</div> <div>Cancel</div>	

### Deleting a Phonebook entry


- Select the entry from the Phonebook list.
- Click **Delete**.

Home

Phone

Phonebook

Phonebook

View option	<input type="text" value="All"/>	
Storage Usage	(SIM - 1/250) (Terminal - 0/100)	
Name	Phone no.	
 Technical	+659821820	

<<

<

1

2

3

4

5

>

>>

Add

Edit

Delete

Send SMS

Refresh

1 row(s) are selected.


## Sending SMS from the Phonebook

Follow these steps to send SMS from the Phonebook:

- i. Select the entry from the Phonebook list.
- ii. Click **Send SMS**.
- iii. The Phonebook console switches over to the Compose SMS console, which will be covered in later section.

Home Phone Phonebook

### Phonebook

View option	
All	
Storage Usage	
(SIM - 1/250) (Terminal - 0/100)	
Name	Phone no.
 Technical	+659821820

<< < 1 2 3 4 5 > >>

Add Edit Delete Send SMS Refresh

1 row(s) are selected.

## 2. Call History

To check history logs of calls made and received.

≡Home	Phone	Call History
-------	-------	--------------

Call History	
View option	All ▾
Phone no.	Time
➡ 006565095706	16/05/05 07:07:52
➡ 00656509706	16/05/05 07:07:35
➡ 006565095706	16/05/05 07:05:40
➡ 006565095706	16/05/05 07:04:42
➡ 006565095706	16/05/05 06:59:28
➡ +870773999250	16/05/05 06:19:08
➡ +870773999250	16/05/05 06:16:56

### View option

The View option allows you to view the Phonebook entries from the different storage locations.

From the drop-down menu, select:

Dialled Call	To view the list of dialled calls only.
Received Call	To view the list of received calls only.
Missed Call	To view the list of missed calls only.
All	To view the list of the dialled, received and missed calls.

## Sending SMS from the Call History

Follow these steps to send SMS from the Phonebook:

- i. Select the entry from the Phonebook list.
- ii. Click **Send SMS**.
- iii. The Phonebook console switches over to the Compose SMS console.

≡Home

SMS

Compose

Compose

Phone no.:

006565095706

📱 71 / 160

2.82853N, 101.28663E, 16/05/05,07:24:33 GMT. Testing Fleet One Terminal

Send

Save

Clear

Refresh

Append GPS

Back To Previous Page

☐ Store a sent copy in SIM

## Deleting a Call History entry

Follow these steps to delete a Call History entry:

- i. Select the entry from the Call History list.
- ii. Click **Delete**.

≡Home







Phone

Call History

Call History

View option

All ▼

Phone no.	Time
 006565095706	16/05/05 07:07:52
 +870773999250	16/05/05 06:19:08
 +870773999250	16/05/05 06:16:56
 +870773999250	16/05/05 06:01:08
 +870773250268	16/05/05 05:10:04
 +870773250268	16/05/05 05:06:22

<<

<

1

2

3

4

5

>

>>

Send SMS


Delete

Refresh


1 row(s) are selected.

### c. SMS Menu

Click on **SMS** Menu



The **Phone** menu has the following options;



#### 1. Compose

To compose and send text messages.

Home

SMS

Compose

Compose

Phone no.:

+49894136478

74 / 160

Will reach the port in 45 mins.  
 40.53298N, 3.65595W, 16/05/01,02:58:37 GMT

Send

Save

Clear

Refresh

Append GPS

☒ Store a sent copy in SIM

- i. Simply enter a mobile number, type your message and click **Send**.
- ii. To save an unsent SMS, click the Save button and the unsent SMS will be saved in **Draft**.
- iii. To clear the typed message on the text editor, click **Clear** button.
- iv. To get update phone list from SIM card or terminal, click **Refresh**.
- v. To include the GPS information in SMS automatically, click **Append GPS** button.

**Note:** Message is limited to 160 characters (using 7 bit encoded default alphabets) including spaces between words. But it is limited to 70 characters per message using Unicode (UCS2) text message (such as message typed in Chinese, Japanese, etc).

**For sending a long SMS to another BGAN transceiver, the message is limited to 608 characters (using 7 bit encoded default alphabet) or 266 characters using Unicode (UCS2) text messages including spaces between words.**

**If you do not wish to store a copy of the sent SMS into SIM card, uncheck "Store a copy in the SIM".**

## 2. Inbox

Shows the details (Sender information, Message, Date and Time stamp) of all SMSs received

Navigation: Home | SMS | **Inbox**

**Inbox**

Storage Usage: 3 / 250

From	Message
— +12057825634	Will reach the port in 45 mins time. 40.53298N, 3.65595W, 16/05/01,02:56:52 GMT

**Date/Time:** 2016/05/01 02:57:30 +0000

Navigation: << < 1 2 3 4 > >>

Actions: Reply Forward Delete Refresh

1 row(s) are selected.

- i. To reply, simply click a SMS to select it and click **Reply**.
- ii. To forward, simply click a SMS to select it and click **Forward** with the recipient's mobile number.
- iii. To delete, select SMS(s) as the shaded grey areas and click **Delete**.
- iv. To update the message, click **Refresh** button.

### 3. Sent

Shows the details (Recipient information and Message, Date and Time stamp) of all SMS received

The screenshot displays the 'Sent' section of the iFleetONE Terminal interface. At the top, there are three navigation buttons: 'Home' (with a hamburger icon), 'SMS', and 'Sent'. Below these is a dark blue header bar with the word 'Sent' in white. The main content area features a 'Storage Usage' indicator showing '4 / 250'. Below this is a table with two columns: 'To' and 'Message'. The 'To' column contains a blue hyperlink '+12057825634'. The 'Message' column contains the text 'Will reach the port in 45 mins time.' followed by coordinates and a timestamp: '40.53298N, 3.65595W, 16/05/01,02:56:52 GMT'. Below the table is a pagination control with buttons for '<<', '<', '1' (highlighted), '2', '3', '4', '>', and '>>'. At the bottom, there are three buttons: 'Forward', 'Delete', and 'Refresh'. Below the 'Delete' button, a status message reads '1 row(s) are selected.'

To	Message
<a href="#">+12057825634</a>	Will reach the port in 45 mins time. 40.53298N, 3.65595W, 16/05/01,02:56:52 GMT

i. To forward, simply click a SMS to select it as the shaded grey area and click **Forward** with the recipient's mobile number.

ii. To delete, select message(s) as the shaded grey areas and click **Delete**.

iii. To update messages, click **Refresh** button.

#### 4. Draft

Stores SMS saved from the Compose console

Home SMS Draft

**Draft**

Storage Usage: 5 / 250

To	Message
+659821820	The handset cannot make a voice call. What is the cause ?

<< < 1 2 3 4 > >>


Send Forward Delete Refresh

1 row(s) are selected.

- i. To send, click a SMS to select it and then click **Send**.
- ii. To forward, click a SMS to select it and click **Forward** with the recipient's mobile number.
- iii. To delete, select message(s) as the shaded grey areas and click **Delete**.
- iv. To update messages, click **Refresh** button.

#### d. Settings Menu

Click on **Settings** Menu




The **Settings** menu has the following options;




## 1. Accounts

To create new user account.



The screenshot shows the 'Accounts' management page. At the top, there are three tabs: 'Home', 'Settings', and 'Accounts', with 'Accounts' being the active tab. Below the tabs is a dark blue header bar with the text 'Accounts'. Underneath, it says 'Users: 1/2'. A list of users is shown in a table with one entry: 'admin'. To the right of the table are three buttons: 'Add' (blue), 'Delete' (yellow), and 'Change Password' (blue).


Click **Add** to add a new user with new password.



The screenshot shows the 'Add User' form. At the top, there are three tabs: 'Home', 'Settings', and 'Accounts', with 'Accounts' being the active tab. Below the tabs is a dark blue header bar with the text 'Accounts'. The form has three input fields: 'Username:' with the value 'user', 'New Password:' with a masked password, and 'Re-type Password:' with a masked password. Below the fields are two buttons: 'Add' (blue) and 'Cancel' (blue). A 'Note' section below the form states: 'For maximum security, password should be min 6 characters long and a combination of uppercase and lowercase letters, numbers and symbols.' Below the note, it shows 'Password Strength: Medium' with a yellow progress bar.

**Note:** The maximum accounts is 2; one is “Admin” and the other is “user”. Their accounts’ names are not editable.


Once the new user account is created, the “user” will appear under **Username**.

A login form for iFleetONE. The title "iFleetONE" is at the top. Below it, there are two input fields: "Username:" with "admin" and "user" as suggestions, and "Password:". A blue "Login" button is at the bottom.

The user account will have limited information and settings in the web console.

A web console navigation menu. It has two buttons at the top: "Home" (with a hamburger icon) and "Settings". Below these are three large, dark blue buttons: "Terminal Info", "Language", and "Support".

## 2. Ethernet



### Ethernet Settings

A screenshot of the 'Ethernet Settings' configuration page. At the top, there are four buttons: 'Home' (with a hamburger icon), 'Settings', 'Ethernet', and 'Ethernet Settings'. Below these is a dark blue header bar with the text 'Ethernet Settings'. Under the header, there is a form with two rows of input fields. The first row is labeled 'Terminal IP Address:' and contains four input boxes with the values '192', '168', '1', and '35'. The second row is labeled 'Terminal Subnet Mask:' and contains four input boxes with the values '255', '255', '255', and '0'. At the bottom of the form, there are two buttons: 'Update' and 'Refresh'.

The Terminal IP Address is the local IP address of the terminal. It is used for accessing the Web Console. By default,

IP address : **192.168.1.35**

Subnet Mark : **255.255.255.0**

See below if you need to change the local IP address and subnet mask.

- i. Enter the **Terminal IP Address** and **Terminal Subnet Mask**.
- ii. Click **Update** to take effect.

## DHCP

Home Settings Ethernet **DHCP**

### DHCP

DHCP:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
DHCP IP Pool Start:	192 . 168 . 1 . 36
DHCP IP Pool End:	192 . 168 . 1 . 254
IP Lease Time:	1800 second(s)

Update Refresh

For the terminal to assign dynamic IP addresses to devices connected to the terminal, the DHCP has to be enabled as follow:

- Click Enabled.
- Set the range of the IP addresses in **DHCP IP Pool Start** and **DHCP IP Pool End**.
- Set the **IP Lease Time** in seconds.
- Click **Update** to take effect.



**WARNING:** IP subnet of 102.168.1.36 is *not allowed* to be used in connected devices as it is reserved for internal use in the terminal.

## MAC Filtering

To disable or enable MAC Filtering with its settings.

Click **MAC Filtering** to view the MAC Filtering settings.

Set the **MAC Filtering** configurations.

**MAC Filtering**

MAC Filtering: ☒ Enabled ☐ Disabled

Use: ☒ Reject List ☐ Allowed List

Reject List	
11:22:33:44:55:66	<input type="button" value="Delete"/>
<input type="text"/>	<input type="button" value="Add"/>
<input type="button" value="Delete All"/>	

\* Your MAC Address: 98:76:54:32:10:12

### Reject List

All PCs/Laptops will be allowed to access the terminal except for those (MAC addresses) listed in the Reject List.


### Allow List

All PCs/Laptops will be denied access to the terminal except for those with MAC addresses listed in the Allow List. When selecting this list, at least one entry should exist to enable access to the terminal.


- Select **Enabled** or **Disabled** to activate/deactivate the MAC Filtering.
- Select **Reject List** or **Allowed List** and then add the MAC addresses.
- Click **Update** to take effect.

### 3. Wi-Fi

To configure the settings of Wi-Fi Base Station.



#### WiFi Setup



- i. Select **Enabled** or **Disabled** to activate / deactivate the Wi-Fi.
- ii. Click **Apply** to take effect.

## System Info

Shows the information of Ethernet MAC Address, WLAN MAC Address and Software version.

≡Home

Settings

Wi-Fi

System Info

### System Info

Ethernet MAC Address	ACCF23B04336
WLAN MAC Address	ACCF23B04334
Software Version	Telnet-Version 11

## Wireless Settings

≡Home

Settings

Wi-Fi

Wireless Settings

### Wireless Settings

Network Mode:	802.11b ▼
Network Name (SSID):	FleetOne
	<input checked="" type="checkbox"/> Allow SSID Broadcast
Channel:	Auto ▼

Update

Refresh

- Choose the preferred **Network Mode** and **Channel**.
- If required, **Network Name (SSID)** can be set or renamed by the user.
- Click **Update** to take effect

## Security Settings

To configure the security settings of Wi-Fi.

Home

Settings

Wi-Fi

Security Settings

### Security Settings

Security Mode

☒ Disabled

☐ WEP

Authentication Type:

Open Key ▾

Default Key:

1 ▾

Key:

☐ WPA - Personal

Encryption Type:

Auto ▾

Passphrase:

☐ WPA2 - Personal

Encryption Type:

Auto ▾

Passphrase:

Update

Refresh

- Select the type of Security Mode; **WEP**, **WPA - Personal** or **WPA2 - Personal**.
- Select the **Authentication / Encryption** Type and type **Key** or **Passphrase**.
- Click **Update** to take effect

## 4. Tracking

The iFleetONE terminal has certain tracking features. It can report to a server at certain time intervals or after travelling a specified distance or over a specified speed limit.



### Tracking Settings

To set up the tracking, click the **Enabled** button for GPS Reporting (recommended for most purposes).

There are 2 modes; IP Data Mode and SMS mode.

### IP Data Mode

Tracking Settings	
GPS Reporting:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Mode:	IP Data ▼
Tracking ID:	EG02bJ
Reporting Interval:	1800
Server Phone Number:	
Server Connection Type:	TCP ▼
Distance Interval:	0 m
Speed Limit (Alarm):	0 km/h
Authorized phone number (1/3):	
Authorized phone number (2/3):	
Authorized phone number (3/3):	
Number of Retries:	2 (0 - 255)
<input type="button" value="Update"/> <input type="button" value="Refresh"/>	

Select **IP Data** and enter the following;

- **Reporting Interval** (in seconds)
- **Distance Interval** (in meters)
- **Speed Limit Alarm** (in km/h)
- **Number of Retries** (from 0 to 255)

No inputs to the boxes of **Server Phone Number**, **Server IP Address\*** and **Server Port\*** are required.

**Note:** \* If you prefer to have your own server with your own IP address and Server Port number, please contact your service provider.

Click **Update** to take effect.

### SMS Mode

Home

Settings

Tracking

Tracking Settings

Tracking Settings

GPS Reporting:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Mode:	SMS
Tracking ID:	EB02bJ
Reporting Interval:	1800
Server Phone Number:	
Server Connection Type:	TCP
Distance Interval:	0 m
Speed Limit (Alarm):	0 km/h
Authorized phone number (1/3):	
Authorized phone number (2/3):	
Authorized phone number (3/3):	
Number of Retries:	2 (0 - 255)

Update

Refresh

Select **SMS** and enter the following;

- **Reporting Interval** (in seconds)
- **Server Phone Number**
- **Distance Interval** (in meters)
- **Speed Limit Alarm** (in km/h)

- **Authorized phone numbers** (to receive SMS)
- **Number of Retries** (from 0 to 255)

Click **Update** to take effect.

## Geo Fence

Home
Settings
Tracking
**Geo Fence**

### Geo Fence

Latitude/Longitude view format: ☒ dddmm.mmmm ☐ ddd.ddddd

Type of Geo Fence	Enabled
<div>Circle</div> <div> <div>Trigger Type:</div> <div>In</div> </div> <div> <div>Perimeter:</div> <div> Latitude : 120.1004  Longitude : 10353.3769  Radius : 50000 m </div> </div>	<input checked="" type="checkbox"/>
<div>Rectangle</div> <div> <div>Trigger Type:</div> <div>Out</div> </div> <div> <div>Perimeter:</div> <div> Latitude, Longitude  120.1419, 10353.3769  216.8912, 10841.5039 </div> </div>	<input type="checkbox"/>
<div>Polygon</div> <div> <div>Trigger Type:</div> <div>In/Out</div> </div> <div> <div>Perimeter:</div> <div> Latitude, Longitude  120.1419, 10353.3769  130.0298, 10814.6113  216.8912, 10841.5039 </div> </div>	<input type="checkbox"/>

Add
Edit
Delete
Refresh

Click the desired view format of Latitude/Longitude.

Click **Add** for adding a Geo Fence definition

i. Select the Latitude/Longitude view format (degrees, minutes and seconds **dddmm.mmmm** or decimal degrees **ddd.dddddd**)

ii. Select Trigger type (**In**, **Out** or **In/Out**).

iii. Select Type of Geo Fence (**Circle**, **Rectangle** or **Polygon**)

iv. Key in Latitude and Longitude values

To modify on current Geo Fence definition, select the desired Geo Fence and then click **Edit**. Click Update after modifying the settings of the Geo Fence.

### APN (Access Point Name)

The screenshot shows the 'APN (Access Point Name)' configuration screen. It features a top navigation bar with buttons for 'Home', 'Settings', 'Tracking', and 'APN (Access Point Name)'. Below this is a header section labeled 'APN (Access Point Name)'. The main configuration area contains two radio button options: 'SIM' (which is selected) and 'User Defined'. The 'SIM' option is associated with a text field containing the value 'BGAN.INMARSAT.COM'. The 'User Defined' option is associated with an empty text field. Below these options are two more text fields labeled 'Username:' and 'Password:'. At the bottom of the form are two buttons: 'Update' and 'Refresh'.

There are 2 options for setting the APN;

- Click **SIM** ( with the setting of “**BGAN.INMARSAT.COM**” for example)

OR

- Click **User Defined** (which you have to enter APN with its username and password. Your air time provider will provide any required APN username and password.)

Then click **Update** to take effect.

## 5. Security



### Terminal PIN

- i. Select **Disabled** if you do not need to set Terminal PIN.
- ii. Select **Enabled** to set the Terminal PIN and then enter PIN number in **Enter PIN** field.
- iii. Click **Apply** to take effect.

### To change the Terminal PIN,

- iv. Enter the old PIN number with new PIN.
- v. Re-enter the new PIN and click **Change PIN password**.

## SIM PIN

≡Home

Settings

Security

SIM PIN

SIM PIN

State	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled
Enter PIN	<input type="text"/>

Apply

Change PIN Password:

Enter Old PIN	<input type="text"/>
Enter New PIN	<input type="text"/>
Re-enter New PIN	<input type="text"/>

Change PIN Password

- i. Select **Disabled** if you do not need to set SIM PIN.
- ii. Select **Enabled** to set the SIM PIN and then enter PIN number in **Enter PIN** field.
- iii. Click **Apply** to take effect.


**To change the SIM PIN,**

- iv. Enter the old PIN number with new PIN.
- v. Re-enter the new PIN and click **Change PIN password**.

## 6. Terminal Settings



### Reboot Terminal



- i. Click **Reboot** to take effect.

## Factory Reset

≡Home

Settings

Terminal Settings

Factory Reset

Factory Reset

Security code:

Factory Reset

**NOTE:**  
Executing "Factory Reset" will reset all of the system configuration settings to default values and clear all user data from the non-volatile memory.

- i. To perform a **Factory Reset**, enter 0000 in the Security Code field.
- ii. Click **Factory Reset** to take effect.



**WARNING:** *Factory Reset will set all of the system configuration settings to default values and clear all user data from the non-volatile memory.*

## Firmware Upgrade

Firmware upgrade is required to update the iFleetONE BDU with the latest firmware. Please refer to your respective distributor for your firmware download.

≡Home

Settings

Terminal Settings

Firmware Upgrade

Firmware Upgrade

Need to reboot in the Firmware Upgrade Mode (Safe Mode). Please do it manually if reboot failed.

Firmware Upgrade

**Disclaimer**

Please be informed that firmware upgrading is done at your own risk and the equipment manufacturer will not be held responsible for any possible malfunction or damage to the system due to upgrading the firmware.

If you encounter any problems or have any questions, please contact the equipment distributor for technical support.



**WARNING:** Do not abort the upgrading process or unplug the power of the BDU during the firmware upgrade process at any time. Doing so will corrupt the existing firmware loading onto the BDU.

- i. Download or acquire the new firmware from your respective distributor and save it in your computer's hard drive.
- ii. Read the Disclaimer message carefully before proceeding with the Firmware Upgrade.
- iii. Click **Firmware Upgrade** and follow instructions.

## Remote Access

By enabling the Remote Access option, an user can remotely (from shore) access the terminal's web console via internet.

Remote Access

Remote Access ☐ Enabled ☒ Disabled

Apply Refresh

- i To enable or disable remote access, select option **Enabled** or **Disabled** respectively.
- ii. Click **Apply** to take effect.

## Ciphering

Enabling the **Ciphering** option will make the terminal to pass voice and data in a secure mode by encrypting them over the air

Ciphering

Ciphering ☐ Enabled ☒ Disabled

Apply Refresh

- i. To enable/disable the **Ciphering**, select the option **Enabled** or **Disabled** respectively
- ii. Click **Apply** to take effect.

### PDP Context Activation via I/O port

The PDP Context Activation via connections to the I/O Port allows for the user of an external physical switch to control the PDP context status.

Navigation: Home, Settings, Terminal Settings, PDP Context Activation via I/O port

**PDP Context Activation via I/O port**

PDP Context Activation via I/O port ☒ Enabled ☐ Disabled

Apply Refresh

- i. To enable/disable the **PDP Context Activation via I/O port**, select the option **Enabled** or **Disabled** respectively.
- ii. Click **Apply** and then **OK** to proceed. This will reboot the terminal.



**WARNING:** The enabled option of PDP Context Activation via I/O port allows the data connection switch to override the activation and deactivation of data connection set on the Web Console.

- iii. There will be no control button of activate or deactivate the data connection on the web console. **PDP context activation via I/O port is enabled.** is displayed, You can use Data Connection External Switch to control the activation/ deactivation of the data connection.

Navigation: Home

**Status:**

Registered to network	Yes
Data connection active	Yes <a href="#">PDP context activation via I/O port is enabled.</a>

Data, Phone, SMS

## SIP Server

The SIP server integrated into the terminal allows a smartphone (through Wi-Fi) or VoIP phone (through the Ethernet cable) to make and receive calls over the BGAN network.

Home

Settings

Terminal Settings

SIP Server

### SIP Server

SIP Server ☒ Enabled ☐ Disabled

**Note**  
SIP Server when enabled, is able to use the Ethernet/Wi-Fi to make and receive phone calls over BGAN satellite network by using IP-Phone/Smartphone.  
[See more.](#)

Apply Refresh

**Note:** Ensure your smartphone has an integrated SIP client.



## Smartphone

You will need to set up the SIP server details as follows in the device before first use:

- Server Address and Port

Address: **192.168.1.35 (Default)**

Port: **5060**

- User Name

Local number in iFleetONE (**0801 to 0804**)

- Password

Default is the same as the User Name.

- Codec Priority

Highest priority codec type: G.711u

**Note:** Every VoIP handset or smartphone connected to the iFleetONE must be set up with a unique number (user name). The maximum number of allowing VoIP handsets and/or smartphones is 4 and only one out of these 4 devices is allowed to make and receive a voice call at a time.

## Facility Lock

The Facility Lock is to provide an option to enable or disable the authentication of AT command access.

The screenshot shows the 'Facility Lock' configuration page. At the top, there is a navigation bar with four buttons: 'Home', 'Settings', 'Terminal Settings', and 'Facility Lock'. Below this is a header for the 'Facility Lock' section. The main content area contains a form with a label '\_ICLCK' and two radio buttons: 'Enabled' (which is selected) and 'Disabled'. At the bottom of the form are two buttons: 'Apply' and 'Refresh'.

- When **\_ICLCK** is enabled and after **Apply** is updated to take effect, you need to carry out a power cycle for the terminal with administrator password. You can access the AT command which requires the use of **"at\_iclck"** with correct user's new password. (for example, **at\_iclck="AD",0,"xxxxxx"** where xxxxxx is the user's new password which has been entered in the web console initially. )

- When **\_ICLCK** is disabled and after **Apply** is updated to take effect, no authentication to access AT command is required. Additionally, with the disabled facility lock, your smartphone can use the Inmarsat Fleet One app which lets you track your location relative to the Fleet One data coverage region.



## Inmarsat Fleet One App

MAP

MAP

FLEET ONE REGION

553.26 NM TO REGION EDGE

OUT OF FLEET ONE REGION

35.71 NM TO REGION EDGE

GPS location:

51.52 N 0.09 W

GPS source:

Fleet One

GPS updated:

15:38 GMT 19-MAY-2016

GPS location:

12.34 N 67.89 E

GPS source:

Manual

GPS updated:

15:38 GMT 19-MAY-2016

DISMISS ALERT

## GPS Output

By default, the iFleetONE BDU outputs the GPS data in NMEA format at 4800 kbps via a serial cable (which is not included in the package). There are other serial speed options of 9600, 19200, 38400, 57600 and 115200 bps which can be selected.



For collecting the debug log messages to diagnose any system issues, the **Output Debug Log** needs to be selected as the debug mode. As the debug mode is not required for a normal end-user, it is recommended to leave the option unchecked.

If required for debug use, the speed is fixed at 11500 bps.

The screenshot shows the 'GPS Output' settings screen. At the top, there is a navigation bar with four buttons: 'Home' (with a hamburger menu icon), 'Settings', 'Terminal Settings', and 'GPS Output'. Below the navigation bar, the title 'GPS Output' is centered. The main content area contains a list of radio button options: 'Output Debug Log (@ 115200bps)' (which is selected), 'Output GPS Data (NMEA)', and a list of baud rates (4800, 9600, 19200, 38400, 57600, 115200). At the bottom right of the content area, there are two buttons: 'Update' and 'Refresh'.

## 7. Terminal Info

The screenshot shows the 'Terminal Info' screen. At the top, there is a navigation bar with three buttons: 'Home' (with a hamburger menu icon), 'Settings', and 'Terminal Info'. Below the navigation bar, the title 'Information' is centered. Underneath, there are three large, stacked buttons: 'Information', 'Logs', and 'Call Log'.

## Information

Displays information about the Manufacture ID, Software Version, Hardware Version, Model ID, IMEI number, IMSI number (only when a SIM card is inserted), Subscriber number, Serial number and Ethernet MAC Address.

Home	Settings	Terminal Info	Information
Information			
Manufacture ID:	Addvalue		
Software Version:	R01.0.2		
Hardware Version:	1		
Model ID:	iFleetONE		
IMEI Number:	352142061000026		
IMSI Number:	901112114509227		
Subscriber Number:			
Serial Number:	ABFV21A161510002		
Ethernet MAC Address:	00:0B:68:02:03:FE		

## Logs

Displays event and error logs of the terminal.

Home

Settings

Terminal Info

Logs

Logs

Event

Logs	Date/Time
Fatal Error 1	2010/1/21 9:10:11
Error 2	2010/1/21 9:10:12
Warning 3	2010/1/21 9:10:13
Information 4	2010/1/21 9:10:14
Fatal Error 5	2010/1/21 9:10:11
Error 6	2010/1/21 9:10:12

<<

<

1

2

3

4

5

6

7

8

>

>>

Delete All

Export All Logs

Error

Logs	Date/Time
GPS error	2010/1/21 10:11:12
ADU communication error	2010/1/21 10:11:13

<<

<

1

2

3

4

5

6

7

8

>

>>

Delete All

Export All Logs

- Click **Export All Logs** so that the system log file will be saved in the computer.
- Send the system log file to your distributor for troubleshooting.

## Call Log

Displays event and error logs of the terminal.

Home
Settings
Terminal Info
Call Log

### Call Log

Phone no.	Call Service	Call Type	Date/Time
+ +6591132319	Standard	Incoming	2013/11/21 10:52:15
+ 006591132319	Standard	Outgoing	2013/11/21 10:51:43
+ +6591132319	Standard	Incoming	2013/11/21 10:51:07
+ 006591132319	Standard	Outgoing	2013/11/21 10:50:29
+ 006591550204	Standard	Outgoing	2013/11/21 10:13:58
+ +6591550204	Standard	Incoming	2013/11/21 10:13:19

<<
<
1
2
3
4
>
>>

### Data Log

Connection Type	Date/Time	Duration	Volume (Upload/Download)	Uplink/Downlink Bitrate (kbps)
+ Background	2013/11/21 11:02:55	000:05:03:19	1.64 MB / 3.32 MB	Dynamic / Dynamic
+ Background	2013/11/21 10:22:09	000:00:25:30	10.49 MB / 10.96 MB	Dynamic / Dynamic


<<
<
1
2
3
>
>>

i. Under **Call Log**, click “+” on any call log to expand it with more information of its duration and cause.

ii. Under **Data Log**, click “+” on any call log to expand it with more information of its IP Address, APN and cause.

## 8. Language

Changes the menu display with the available languages.



- i. Select the desired language available in the Web Console.
- ii. Click **Apply** to take effect.

## 9. Support

Displays the information of Inmarsat Distribution Partner name, contact information of support (phone number and email address) and the URL links of support and services.


## 10. About

Displays the copyright statement with Addvalue Enabled logo



### e. Logout Menu

Click on **Logout** Menu and it will return to the screen where you are required to login again.



### GLOSSARY

<b>ADU</b>	Above Decks Unit
<b>APN</b>	Access Point Name
<b>ATB</b>	Antenna Tracking Board
<b>BDU</b>	Below Decks Unit
<b>DC</b>	Direct Current
<b>FTP</b>	File Transfer Protocol
<b>GPS</b>	Global Position System
<b>GPIO</b>	General Purpose Input / Output
<b>HPA</b>	High Power Amplifier
<b>IP Data</b>	Internet Protocol Data
<b>NAT</b>	Network Address Translation
<b>PAT</b>	Port Address Translation
<b>PDP</b>	Packet Data Protocol
<b>PIN</b>	Personal Identification Number
<b>PSTN</b>	Public Switched Telephone Network
<b>SIM</b>	Subscriber Identity Module
<b>UE</b>	User Equipment